## Quick Installation

# MOBOTIX MOVE 5MP IR Vandal Turret Mx-VT1A-5-IR

© 2025 MOBOTIX AG

#### NOTE!

This guide is only valid for **installing and connecting** the 5MP IR Vandal Turret. For more information on the camera, please refer to the other documents (see Further Reading, p. 9).


#### **Important Installation Notes**

- This camera must be installed by qualified personnel and the installation should conform to all local codes.
- This product must not be used in locations exposed to the dangers of explosion.
- Do not use this product in a dusty environment.
- Protect this product from moisture or water entering the housing.
- Install this product as outlined in this document. A faulty installation can damage the product!
- Do not replace batteries of the camera. If a battery is replaced by an incorrect type, the battery can explode.
- This equipment is not suitable for use in locations where children are likely to be present.
- External power supplies must comply with the Limited Power Source (LPS) requirements and share the same power specifications with the camera.
- When using a power adapter, the power cord shall be connected to a socket-outlet with proper ground connection.
- To comply with the requirements of EN 50130-4 regarding the power supply of alarm systems for 24/7 operation, it is highly recommended to use an uninterruptible power supply (UPS) for backing up the power supply of this product.

**NOTE!** To ensure that the unit is not affected by vibration, twisting, etc. after adjusting the camera, properly tighten all mounting screws.


### **Package Contents**

Check the package for the items listed below.



### **Disassembling the Camera**

- 1. Loosen the screw ① on the top cover using the T10 Torx wrench.
- 2. Remove the top cover ②.
- 3. Carefully remove the camera lens module 3 from the bottom camera case 4.



### **Inserting the SD Card**

**CAUTION!** Always power down the camera before performing the following steps!


- 1. Remove the SD card cover ① from the camera lens module by loosening the screws ① with the T10 Torx wrench.
- 2. Insert the SD card into the corresponding slot.
- 3. Reattach the SD card cover.



#### NOTE!

• It is not recommended to record with the microSD card for 24/7 continuously, as it may not be able to support long term continuous data read/write. Contact the manufacturer of the microSD card for information regarding the reliability and the life expectancy.

### **Mounting the Camera**




Mounting the camera routing the ethernet cable through the Surface


Mounting the camera routing the ethernet cable on the surface

1. Attach the drilling template to the wall or ceiling.

**NOTE!** You can choose to drill two or three holes on the mounting template. The following instructions are be based on three holes.



- 2. Drill the three holes according to the drilling template and insert the plastic dowels supplied.
- 3. If applicable, drill a hole for the cable gland.
- 4. Only when routing the ethernet cable through the surface attach the cable entry cover.
- 5. Use the self-tapping screws ① to attach the camera bottom case to the mounting surface ② prepared with the wall plugs.




6. Attach the waterproof cover ③ to the ethernet cable.




7. Connect the ethernet cable with the RJ-45 port of the camera and firmly close the waterproof cover.

#### NOTE!


- The length of the Ethernet cable should not exceed 100 m/300 ft.
- In some cases, an Ethernet crossover cable may be needed when connecting the camera directly to the PC.
- 8. Align the groove on the top cover ④ with the rim one the camera bottom case and attach the camera lens module and top cover to the camera bottom case.



**NOTE!** Make sure the triangle arrow ⑤ is facing upwards



9. Adjust the camera lens module to the desired field of view.



10. Close the housing screw ⑥ with the T10 Torx key to securely fasten the top cover to the lower camera housing.

#### **Client System Requirements**

#### **System Hardware**

CPU	i5-2430M CPU@ 2.40GHZ
RAM	6 GB or above
Display	NVIDIA GeForce 6 Series or ATI Mobility Radeon 9500
Power Supply	PoE (IEEE 802.3af Class 3)
Network	10/100BASE-T Ethernet (RJ-45 connector)

#### **System Software**

Operating System	Microsoft Windows 10 or above, MacOS Sierra or above
Browser	Mozilla Firefox, Google Chrome, Apple Safari, Microsoft Edge

#### **Accessing the Camera**

#### NOTE!

This MOBOTIX MOVE camera is designed for full integration with MOBOTIX and third-party software and recording solutions using common ONVIF S/G/T&M profiles.

When integrating this camera into MOBOTIX environments (e.g. MOVE NVR, MOVE CMS, MOBOTIX HUB MxMC, MOBOTIX CLOUD etc.) or third-party software, please use the ONVIF device search and integration method only.

The IP address of the camera can be found on the label on the camera housing.

- 1. Access the IP address of the camera with a web browser.
- 2. If you are accessing the camera's web interface for the first time, you must change the administrator password for user "ADMIN".

#### This Camera is Not Secure



#### NOTE!

The password must include at least

- 8 characters including
- 1 uppercase letter
- 1 special character

Further information about using the camera can be found in the "User Manual."

## **Further Reading**



