

Guideline

Vaxtor LPR incl. Vehicle Make, Model, Color and Class App

© 2025 MOBOTIX AG




Table of Contents

Table of Contents	2
Before You Start	5
Support	6
MOBOTIX Support	6
MOBOTIX eCampus	6
MOBOTIX Community	6
Safety Notes	7
Legal Notes	7
About Vaxtor LPR incl. Vehicle Make, Model, Color and Class App	9
Smart Data Interface to MxManagementCenter	9
Technical Specifications	10
Licensing Certified Apps	13
License Activation of Certified Apps in MxManagementCenter	13
Managing Licenses in MxManagementCenter	17
Camera, image and scene requirements	20
Recommendations on mounting and adjusting.	23
Activation of the Certified App Interface	25
Configuration of Vaxtor LPR incl. Vehicle Make, Model, Color and Class App	27
Basic Settings	28
Recognition Areas	29
Drawing a rectangular Area in the Live View	29
List Management	30
Video	31
License Plates	32
Environment	32
OCR	34
MMC	35
Reporting	35
Basic Settings	37
Text Overlay	37
MxMessage	38
MOBOTIX HUB Analytic Event	38
MOBOTIX HUB Transaction	38
MOBOTIX SYNC	39
JSON	40

XML	40
Milestone Analytic Event	41
TCP Client	41
TCP Server	41
FTP	42
Network Optix	43
Genetec Security Center	44
Variables / Template Fields	45
Genetec LPR Plugin	50
UTMC	51
Advanced	52
Storing the Configuration	53
MxMessageSystem	54
What is MxMessageSystem?	54
Facts about MxMessages	54
MxMessageSystem: Processing the automatically generated app event	55
Checking automatically generated app events	55
Action handling - Configuration of an Action Group	56
Action settings - Configuration of the camera recordings	59
Advanced Configuration: Processing the meta data transmitted by apps	61
Meta data transferred within the MxMessageSystem	61
Creating a Custom Message Event	62
Examples for message names and filter values of the Vaxtor LPR incl. Vehicle Make, Model, Color and Class App	64

Before You Start

Support	6
Safety Notes	7
Legal Notes	7

Support

MOBOTIX Support

If you need technical support, please contact your MOBOTIX dealer. If your dealer cannot help you, he will contact the support channel to get an answer for you as quickly as possible.

If you have internet access, you can open the MOBOTIX help desk to find additional information and software updates.

Please visit www.mobotix.com > [Support](#) > [Help Desk](#).



MOBOTIX eCampus

The MOBOTIX eCampus is a complete e-learning platform. It lets you decide when and where you want to view and process your training seminar content. Simply open the site in your browser and select the desired training seminar.

Please visit www.mobotix.com/ecampus-mobotix.



MOBOTIX Community

The MOBOTIX community is another valuable source of information. MOBOTIX staff and other users are sharing their information, and so can you.

Please visit community.mobotix.com.



Safety Notes

- This camera must be installed by qualified personnel and the installation should conform to all local codes.
- This product must not be used in locations exposed to the dangers of explosion.
- Do not use this product in a dusty environment.
- Protect this product from moisture or water entering the housing.
- Install this product as outlined in this document. A faulty installation can damage the product!
- Do not replace batteries of the camera. If a battery is replaced by an incorrect type, the battery can explode.
- External power supplies must comply with the Limited Power Source (LPS) requirements and share the same power specifications with the camera.
- When using a power adapter, the power cord shall be connected to a socket-outlet with proper ground connection.
- To comply with the requirements of EN 50130-4 regarding the power supply of alarm systems for 24/7 operation, it is highly recommended to use an uninterruptible power supply (UPS) for backing up the power supply of this product.

Legal Notes

Legal Aspects of Video and Sound Recording

You must comply with all data protection regulations for video and sound monitoring when using MOBOTIX AG products. Depending on national laws and the installation location of the cameras, the recording of video and sound data may be subject to special documentation or it may be prohibited. All users of MOBOTIX products are therefore required to familiarize themselves with all applicable regulations and to comply with these laws. MOBOTIX AG is not liable for any illegal use of its products.

Declaration of Conformity

The products of MOBOTIX AG are certified according to the applicable regulations of the EC and other countries. You can find the declarations of conformity for the products of MOBOTIX AG on www.mobotix.com under **Support > Download Center > Marketing & Documentation > Certificates & Declarations of Conformity**.

RoHS Declaration

The products of MOBOTIX AG are in full compliance with European Unions Restrictions of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS Directive 2011/65/EC) as far as they are subject to these regulations (for the RoHS Declaration of MOBOTIX, please see www.mobotix.com, **Support > Download Center > Marketing & Documentation > Brochures & Guides > Certificates**).

Disposal

Electrical and electronic products contain many valuable materials. For this reason, we recommend that you dispose of MOBOTIX products at the end of their service life in accordance with all legal requirements and regulations (or deposit these products at a municipal collection center). MOBOTIX products must not be disposed of in household waste! If the product contains a battery, please dispose of the battery separately (the corresponding product manuals contain specific directions if the product contains a battery).

Disclaimer

MOBOTIX AG does not assume any responsibility for damages, which are the result of improper use or failure to comply to the manuals or the applicable rules and regulations. Our General Terms and Conditions apply. You can download the current version of the **General Terms and Conditions** from our website at www.mobotix.com by clicking on the corresponding link at the bottom of every page.

It is the User's responsibility to comply with all applicable local, state, national and foreign laws, rules, treaties and regulations in connection with the use of the Software and Product, including those related to data privacy, the Health Insurance Portability and Accountability Act of 1996 (HIPPA), international communications and the transmission of technical or personal data.

About Vaxtor LPR incl. Vehicle Make, Model, Color and Class App

Worldwide usable vehicle identification

Based on deep learning processes the certified Vaxtor LPR incl. Vehicle Make, Model, Color and Class App recognizes license plates as well as vehicle's make, model, color and class (MMC). The app can be used at maximum speeds of up to 160 km/h (LPR only) and 100 km/h (plus MMC) on two lanes and by an extremely high hit probability of over 99 percent.

Via blocking or permission lists, authorized, blocked or searched vehicles can be defined specifically. For example, a gate or barrier in an access road can open or be blocked automatically.

- Subject to license, single payment for unlimited use
- Recognition of license plates with global country coverage
- Recognition of make, model, color and class
- Over 99% accuracy and high-speed performance
- Use of blocking and permission lists possible
- App-integrated Smart Data Data Interface for data retrieval with MxManagementCenter version 2.4 or higher

CAUTION! Thermal sensors are not supported by this app.

Smart Data Interface to MxManagementCenter

This app has a Smart Data interface to MxManagementCenter.

With the MOBOTIX Smart Data System, transaction data can be linked to the video recordings made at the time of the transactions. Smart Data source can be e.g. MOBOTIX Certified Apps (no license required) or general Smart Data sources (license required) like POS systems or license plate recognition systems.

The Smart Data System in MxManagementCenter enables you to quickly find and review any suspicious activities. The Smart Data Bar and the Smart Data View are available for searching and analyzing transactions. The Smart Data Bar provides a direct overview of the most recent transactions (from the last 24 hours) and for this reason it is convenient to use it for reviews and searches.

NOTE! For information on how to use the Smart Data System, see the corresponding online help of the camera software and MxManagementCenter.

Technical Specifications

Product Information

Product Name	Vaxtor LPR incl. Vehicle Make, Model, Color and Class App
Order Code	Mx-APP-VX-MMC
Supported MOBOTIX Cameras	Mx-M73A, Mx-S74A
Minimum Camera Firmware	V7.1.3.15
MxManagementCenter Integration	<ul style="list-style-type: none">min. MxMC v2.4.4Configuration: Advanced Config license requiredRecognition Log & Forensic Search: Smart Data Interface license included

Product Features

App Features	<ul style="list-style-type: none">License plate recognition of one- and two-line license platesSupport of latin, hebrew and arabic characters for global applicationAdditional recognition of vehicle make, model, color and classRecognition log (Smart Data / Event Search via MxManagementCenter)MOBOTIX events via MxMessageSystemTwo lists for individual actions (e.g. access granted/denied, alarm, etc.)Free flow and Signaled mode
Maximum number of lanes	2
Maximum number of enrolled license plates	1000 per list
Meta Data / Statistic formats	JSON
Trial License	30-day trial license pre-installed
MxMessageSystem supported	Yes
Interfaces	<ul style="list-style-type: none">MxMC Smart Data

- IP Notification
- Milestone X-Protect
- MOBOTIX SYNC
- generic 3rd party integration via XML
- compare supported camera's interfaces

MOBOTIX Events Yes

ONVIF Events Yes (Generic Message event)

Supported Vehicles

No. of supported Car Makes > 470

No. of supported Car Models > 7500

Supported Vehicle Colors Black, White, Grey, Blue, Red, Green, Brown, Beige, Gold, Yellow, Violet, Orange

Supported Vehicle Classes Car, Van, Truck, Bus, Motorcycle

Supported Countries

Supported license plates / countries / <https://community.mobotix.com/t/vaxtor-lpr-app-supported-license-plates-countries>

Scene Requirements

Character Height 20px - 50px (depending on the plate type)

Maximum Vertical Angle 30°

Maximum Horizontal Angle < 25°

Maximum Tilt Angle < 25°

Technical App Specifications

Synchronous / Asynchronous App Asynchronous

Simultaneous execution of other apps Yes (considering performance requirements)

Technical Specifications

Smart Data Interface to MxManagementCenter

Accuracy	Min. 99% (considering scene requirements)
Processed number of frames per second	Typ. 10 fps
LPR Detection time	Typ. 100 – 120 ms
Classification time	Typ. 100 - 120 ms
Classification & MMC	Typ. 250 ms

Licensing Certified Apps

The following licenses are available for the Vaxtor LPR incl. Vehicle Make, Model, Color and Class App:

- **30-day test license** pre-installed
- **permanent commercial license**

The usage period begins with activation of the app interface (see [Activation of the Certified App Interface](#))

NOTE! For buying or renewing a license, contact your MOBOTIX Partner.

NOTE! Apps are usually pre-installed with the firmware. In rare cases, apps must be downloaded from the website and installed. In this case see www.mobotix.com > [Support](#) > [Download Center](#) > [Marketing & Documentation](#), download and install the app.

License Activation of Certified Apps in MxManagementCenter

After a test period commercial licenses must be activated for use with a valid license key.


Online-Activation

After receiving the activation IDs, activate them in MxMC as follows:

1. Select from the menu **Window > Camera App Licenses**.
2. Select the camera on which you want to license apps and click **Select**.


Licensing Certified Apps

License Activation of Certified Apps in MxManagementCenter





NOTE! If necessary, correct the time set on the camera.

1. An overview of the licenses installed on the camera may be displayed. Click **Activate License**.



NOTE! If necessary, correct the time set on the camera.

2. Enter a valid Activation ID and specify the number of licenses to install on this computer.
3. If you want to license another product, click on . In the new row, enter the appropriate Activation ID and the number of licenses you want.
4. To remove a line click .

- When you have entered all Activation IDs, click **Activate License Online**. During activation, **MxMC** connects to the license server. This requires an Internet connection.




Fig. 1: Adding licenses

Successful activation

After successful activation, a new log in is required to apply the changes. Alternatively, you can return to license management.

Failed activation (missing internet connection)

If the license server cannot be reached, e.g. due to a missing internet connection, apps can also be activated offline. (see [Offline Activation](#), p. 15).


Offline Activation

For offline activation, the partner/installer from whom you purchased the licenses can generate a capability response (.bin file) on the license server to activate their licenses.

- Select from the menu **Window > Camera App Licenses**.
- Select the camera on which you want to license apps and click **Select**.


Licensing Certified Apps

License Activation of Certified Apps in MxManagementCenter




NOTE! If necessary, correct the time set on the camera.

3. An overview of the licenses installed on the camera may be displayed. Click **Activate License**.




NOTE! If necessary, correct the time set on the camera.

4. Enter a valid Activation ID and specify the number of licenses to install on this computer.

5. If you want to license another product, click on . In the new row, enter the appropriate **Activation ID** and the number of licenses you want.

6. If necessary, click  to remove a line.
7. When you have entered all Activation IDs, click **Download Capability Request File (.lic)** and send it to your partner/installer.

NOTE! This file allows the partner / installer from whom you purchased the licenses to generate a capability response file (.bin) on the license server.



8. Click Load Capability Response File and follow the instructions.


Successful activation

After successful activation, a new log in is required to apply the changes. Alternatively, you can return to license management.


Managing Licenses in MxManagementCenter

In MxManagementCenter you can comfortably manage all licenses that have been activated for a camera.

1. Select from the menu **Window > Camera App Licenses**.
2. Select the camera on which you want to license apps and click **Select**.



An overview of the licenses installed on the camera may be displayed.



NOTE! If necessary, correct the time set on the camera.

Column

Explanation

Name

Name of the licensed app

Expiration

the time limit of the license

Quantity

Number of licenses purchased for a product.

Serial Number

Unique identification determined by MxMC for the device used. If problems occur during licensing, please have the device ID ready.

Synchronize licenses with server

When the program starts, there is no automatic comparison of the licenses between the computer and the license server. Therefore, click **Update** to reload the licenses from the server.

Update licenses

To update temporary licenses, click **Activate Licenses**. The dialog for updating/activating licenses opens.

NOTE! You need administrator rights to synchronize and update licenses.

Camera, image and scene requirements

The camera should be setup so that the combination of the distance, the lens's focal length and the camera's resolution provide an image that can be accurately analyzed by the OCR. Therefore the following pre-requisites must be fulfilled for the scene:

Quality of the license plate to be captured in the image

- The license plate must be high-contrast and clearly legible, i.e. as clean as possible, without dents or holes and well illuminated.
- The license plate should be rectangular
- Minimum character height
 - The objective of an ALPR system is to capture an image with a good readable plate. In order to achieve this the characters on the plate should have a height between 20 and 30 pixels for larger plate formats (e.g. EU 50cm plates) and about 25-35 pixels for USA-style plates which are physically smaller and have a narrow character stroke width in many states.)
 - Certain Middle East and Arabic plates are smaller still and will need an even greater character pixel height of say 30-40 pixels. For example, in Abu Dhabi the small characters next to or above the main characters are only 3cm high and may require a much higher camera resolution.




Fig. 2: Minimum character height

- Maximum rotation angle:



Fig. 3: Maximum rotation angle

- Vertical: < 30°
- Slope: < 25°
- Horizontal: < 25°

Frame rate

The selection of the correct frame rate influences the recognition quality significantly. For ALPR cameras, the following frame rates are recommended:

Examples for recommended frame rates

Scene (Street type)	minimum frame rate (fps)
Barrier or Gate	5
Normal city street	15
Fast city streets	20
Freeway	25

Shutter Speed (Exposure time)

Shutter speed, also known as the “exposure time”, is the length of time a camera shutter is open for in order to expose light onto the camera sensor. The shutter speed is measured in seconds, or fractions of a second. The bigger the denominator, the faster the speed. For example, 1/250th means one two-hundred-and-fiftieth of a second or four milliseconds.

(1 second = 1000 milliseconds)

Examples for recommended exposure times

Scene (Street type)	minimum exposure time (sec)
Barrier or Gate	1/250 th (4 milliseconds)
Normal city street	1/500 th (2 milliseconds)
Fast city streets	1/1000 th (1 milliseconds)
Freeway	1/1000 th (1 milliseconds)

NOTE! he exposure time must be adjusted according to the light conditions.

Resolution

The resolution of the camera determines the amount of detail that can be captured. The smaller the object detail, the higher the resolution that is required. There are several factors that determine the detail captured:

- The resolution (pixel size) of the camera sensor. This sensor (normally CMOS) where the light eventually falls and a typical IP camera has a sensor resolution of 2 or 4 Megapixels.
- The resolution of the camera's electronics. Most CCTV cameras can support a minimum of 1920 x 1080 – but may be set to a lower resolution if not needed.
- The quality and focal length of the lens. The quality of the optics can play a part in challenging circumstances. The focal length (zoom factor) determines the field of view that can be seen.
- The quality of the images can be influenced by factors such as the type of lighting used.

Examples for recommend resolutions

Scene (Street type)	minimum resolution
Barrier or Gate	800 x 600 px
Roadside Deployment	1280 x 720

Focal length

The focal length of the lens determines how “zoomed in” the image is. It is usually expressed in millimeters (e.g., 6 mm, 25 mm, or 50 mm).

The focal length defines the angle of view (how much of the scene will be captured) and the magnification (how large individual elements will be). The longer the focal length, the narrower the angle of view and the higher the magnification. The shorter the focal length, the wider the angle of view and the lower the magnification.

In the case of zoom lenses, both the minimum and maximum focal lengths are stated, for example 10–40 mm.

Examples for recommended focal length

Scene (Street type)	Distance between camera and license plate (m)	recommended lens
Barrier or Gate	2 - 6 m	2 - 8 mm or similar
Highway, road or street	15 - 30 m	15 - 50 mm or similar

NOTE! The lens should be **IR corrected** to avoid out of focus images. IR Corrected lenses should be used on both day/night and monochrome cameras in all lighting conditions in order to achieve a crisp sharp image.

Infrared illumination

Infrared (or IR) illuminators are designed to provide additional illumination that the camera can see but humans normally cannot. In low light conditions, an IR illuminator is used as a spotlight to facilitate 24-hour recognition. It can penetrate darkness and to a lesser extent fog, rain and snow and it eliminates the inconsistency of ambient light.

Infrared illuminators add light across the camera's field of view to produce the desired image quality, lighting up the area and reflecting the plate.

For ALPR, it is recommended that the camera always has an infrared illuminator. This can be built into the camera or added as an external unit providing that it is placed very close to the camera lens.

Recommendations on mounting and adjusting.

- If you want to recognize license plates on multiple lanes it is generally recommended to mount the camera on a crossbar.
- Use an IR Led to recognize license plates at night or under low light conditions.
- Shutter speed must be high enough to cut the light from car's headlights at night (usually it's about 1/1000). Keep in mind, that too high shutter speed may obscure the edges of the lines (especially shadows).
- Depth of focus is a very important parameter. If you are using a camera with a CS-mount lens, use a fixed lens. Fixed lens are better for license plate recognition due to greater depth of focus. Megapixel lens is also strongly recommended.
- Respect changing light conditions (e.g. due to sunrises and sunset) when choosing the place of mounting. Direct sunlight beams can distort a picture. If the cars facing a direct sunlight consider using a lens with auto iris mode.
- If mounting a camera on a roadside pole check how the pole reacts to heavy cars or a convoy of cars. Some poles have tangible tremor, this could make license plate recognition almost impossible.

Camera, image and scene requirements

Recommendations on mounting and adjusting.

- It is recommended to turn down WDR and BLC. In most cases, they will make the picture more pretty, but at the cost of smudging details like an edges of letters in the license plate. For the same reason keep digital noise reduction as low as possible.
- On certain rare conditions there may be a cases of false detections e.g. because of recognizing image parts that structurally or semantically look similar to a license plate(e.g. fences or ads). To minimize this:
 - Adjust the region of interest accordingly. It may be a good idea to make it smaller, or change it's shape, omitting the parts, which potentially may be false detected.
 - Adjust the min and max license plate settings according to upper instructions do not leave a default 130 - 300.
 - There may be cases, when the best performance will occur by changing angle of lens or moving the camera. In some cases, shooting a front license plate is better.

Activation of the Certified App Interface

CAUTION! The Vaxtor LPR incl. Vehicle Make, Model, Color and Class App does not consider obscure areas defined for the live image. Therefore there is no pixelation in obscure areas while configuring the app and during image analysis by the app.

NOTE! The user must have access to the setup menu ([http\(s\)://<camera IP address>/control](http(s)://<camera IP address>/control)). Therefore check the user rights of the camera.

1. In the camera web interface, open: **Setup Menu / Certified App Settings** ([http\(s\)://<camera IP address>/control/app_config](http(s)://<camera IP address>/control/app_config)).

The screenshot displays the MOBOTIX Certified App Settings web interface. At the top, the browser title is 'M73 mx10-32-4-98 Certified App Settings'. The 'General Settings' section includes:

- Arming**: Active (1). Description: Activate app service.
- Resource monitor**: Active. Description: Display camera actual load in the live image.
- Custom font**: Active. Description: Use custom font for the text displays in the live image. To select or upload a custom font, please go to [Manage Font File](#).

The 'AppSettings' section contains a table with the following data:

App	Activation	License	Explanation	Version	Delete	Delete app	Download Support Information
Vaxtor ALPR MMC Settings	<input checked="" type="checkbox"/> (2)	Vaxtor ALPR MMC: 2024-12-03 (30 days trial).	Vaxtor ALPR MMC	1.6.20	Data (0)	Delete app	

At the bottom of the interface, there are three buttons: 'Set factory' (3), 'Restore', and 'Close'.

2. Under **General Settings** activate the **Arming** (1) of the app service (see screenshot).
3. Under **App Settings** check the **Activation** (2) option and click **Set** (3) .
4. Click on the name of the App to be configured to open the Apps user interface.

Activation of the Certified App Interface

Recommendations on mounting and adjusting.

5. For configuration of the App see [Configuration of Vaxtor LPR incl. Vehicle Make, Model, Color and Class App](#), p. 27

Configuration of Vaxtor LPR incl. Vehicle Make, Model, Color and Class App

NOTE! For best performance and results in LPR and ADR processing make sure to have scene set up to meet the [Camera, image and scene requirements, p. 20](#).

CAUTION! The user must have access to the setup menu ([http\(s\)://<camera IP address>/control](http(s)://<camera IP address>/control)). Therefore check the user rights of the camera.

1. In the camera web interface, open: **Setup Menu / Certified App Settings** ([http\(s\)://<camera IP address>/control/app_config](http(s)://<camera IP address>/control/app_config)).
2. Click on the name of the **Vaxtor LPR incl. Vehicle Make, Model, Color and Class App**.

The configuration window of the app appears with the following options:

Basic Settings

Multiple countries can be selected from more to less probability of occurrence. Therefore the following configurations should be taken into account:

Vaxtor ALPR MMC		
Countries	Spain <input type="button" value="X"/> <input type="button" value="+"/>	Choose countries from more to less probability of occurrence (up to 10)
Enable Grammar Strict	<input checked="" type="checkbox"/>	Read only the plates that match the selected countries
Working Mode	Freeflow <input type="button" value="v"/>	Signaled: The application will only attempt to read a license plate number when the signal is activated. Freeflow: The application continuously captures license plate numbers.
Analytics Complexity	Medium <input type="button" value="v"/>	Tip: Set low if you're losing plates because lack of performance, Medium: default/normal scenario conditions, High: low quality video
Vehicle Analytics	<input checked="" type="checkbox"/>	Enable or disable the vehicle analytics: Make, Model, Color, Classification and Pose estimation
Enable MxMessage	<input checked="" type="checkbox"/>	Send a mxmessage when a plate is read
Enable Overlay	<input checked="" type="checkbox"/>	Display an overlay on all the sensors when a plate is read

Countries: Select at least one country and ensure that you select in the more to less probability of occurrence.

To add country select it and click the + button.

To remove a country click on the x button beside it.

Grammar strict: Check to force the Engine to only use the syntax from countries or states that you have selected. Plates that do not match these rules will not be reported. This is the recommended option for using ALPR for access control where exact matches are required

NOTE! In the USA, the same license plates of various other states can be on the road in one state and thus be detected. The recommended setting is OFF.

Working mode: The following modes are available:

Free flow: The application continuously captures license plate numbers.

Signaled: The application will only attempt to read a license plate number when the signal (trigger) is activated.

NOTE! In signaled mode an signal ID will be sent with the signal event.

MxMessage: Check to enable the processing of LPR (MMC) events in the MxMessageSystem.

Enable Overlay: Check to enable the display of the license plate recognition result in the live view.

Recognition Areas

A Recognition Area, an area within the video frame where the OCR analytics takes place. You can draw a polygon and choose whether the area to look for plates in Inside or Outside this region. You can set multiple areas to respect complex situations.

NOTE! Using Recognition Areas can decrease OCR processing time and also reduce false positives. The whole license plate must be in or out the Recognition Area to pass the test.

Recognition Area Type: Check to activate the sending of events according to the following configuration

Inclusion: only the plates inside the recognition area will be detected.

Exclusion: only the plates outside the recognition area will be detected.

Show Recognition Area: Check to display the recognition area on the LPR sensor.

Edit Recognition Area: Click **Edit Rectangle**① to draw a recognition area in the live view (see [Drawing a rectangular Area in the Live View, p. 29](#)).

Recycle Bin icon ② : Click the to delete the recognition area.

Plus icon ③ : Click the to define another Detection Area.

Drawing a rectangular Area in the Live View

In the Live View, there you can draw rectangular area. Depending on the App these areas are e.g. Detection Areas, Excluded Areas, Reference Areas, Human Size Selectors etc.

1. In the Live View simply click and drag a rectangular area.
2. Drag the corner points to the desired position.
3. In the top right corner of the live view click **Submit** to adopt the coordinates of the polygon.
4. Optionally click the **bin** icon to delete the recognition area.

List Management

You can define a black list and a white list with up to 1000 license plates per list. If a license plate from one of the lists is recognized, a corresponding event is sent within the MxMessageSystem of the camera.




Fig. 4: Black and white lists

Adding a license plate to a list

1. Enter the license plate text into the text field ① and click **Enter**.

Adding multiple license plates from a text file

1. Make sure that your text file contains one license plate per line.
2. Copy the relevant license plates from the text file and paste them into the text field ①.

Deleting a license plate from a list

1. Click on the small x ② to the right of the license plate number.

Deleting all license plates from a list

1. Click the trash icon ③ .

Sorting all license plates from a list alphabetically

1. Click the sort icon ④ .

Copy all license plates from a list to the clip board

1. Click the copy to clipboard icon ⑤ .

Filtering license plates

1. Enter the license plate or parts of it into the filter text field ⑥ . Only license plates containing the filter text are displayed accordingly.

Video

In the video tab you can specify video quality of the video to be analyzed.

Video		
LPR Sensor	Right sensor	Sensor used to recognize license plates
Overview Sensor	None	Sensor used to capture overview images when a plate is detected
Resolution	1920x1080	Working resolution. Adjust the resolution and the camera zoom to capture the plates on the optimum range. Changing this option will require a camera reboot
Minimum Character Height	18	Minimum character height in pixels (14-70). Tip: optimal reading size is 25 pixels height
Maximum Character Height	42	Maximum character height in pixels (14-70). Tip: optimal reading size is 25 pixels height

LPR sensor: Select the camera sensor to be used for License plate recognition.

NOTE! Changing this option requires a camera reboot.

Overview Sensor: Optionally select a sensor used to capture overview images when a plate is detected.

Resolution: Set the working resolution (current max = 1080p). Adjust the resolution and the camera zoom to capture the plates on the optimum range.

NOTE! Changing this option requires a camera reboot.

Minimum Character Height: the minimum height that a license plate's characters should be before being read. The characters should be about 20-30 pixels high.

NOTE! For small license plates, e. g most Arabic plates or plates with additional small characters e.g. Costa Rica a minimum character height of 30 pixels is recommended.


The recommended difference between the min and max heights is about 10 pixels

Maximum Character Height: the maximum height is about 20-30 pixels.

NOTE! The recommended difference between the min and max heights is about 10 pixels.

License Plates

In the License Plates tab you can refine the settings for the license plates to be analyzed.

License Plates		
Minimum Plate Characters	<input type="text" value="4"/>	Minimum number of characters that the license plate may have (2-16)
Maximum Plate Characters	<input type="text" value="12"/>	Maximum number of characters that the license plate may have (2-16)
Multiline Reading	<input checked="" type="checkbox"/>	Read plates with 2 lines

Minimum Plate Characters: Minimum number of characters that the license plate may have (2-16).

Maximum Plate Characters: Maximum number of characters that the license plate may have (2-16).

Multiline Reading: set if license plates with 2 lines should be read.

Environment

In the Environment tab you can set parameters in respect the environmental situation the license plates are to be analyzed.

Environment ✖		
Same Plate Delay	<input type="text" value="60"/>	Minimum elapsed time to report the same plate twice (seconds)
Same Plate Character Distance	<input type="text" value="2"/>	Maximum difference between two plates to be considered as the same (Levenshtein distance)
Maximum Slope Angle	<input type="text" value="20"/>	License plate maximum slope angle (0-30)
Maximum Recognition Period	<input type="text" value="500"/>	Maximum time the OCR can spend reading one or more times the same plate (multiple samples) until making its final decision (ms)
Minimum Plates Occurrences	<input type="text" value="1"/>	Minimum number of times the plate should be read within the "Max Recognition Period"
Maximum Plates Occurrences	<input type="text" value="5"/>	Maximum number of times the plate should be read within the "Max Recognition Period". If the OCR reaches this number before the maximum recognition period expires, it will force out the plate result
Reported Image	<input type="text" value="First"/>	Define which image from the pool is returned with the metadata

Fig. 5: Environment

Same Plate Delay: Minimum elapsed time in seconds to report the same plate twice. This is to prevent multiple reporting of the same plate in situations when the traffic is slow or stationary.

NOTE! If a vehicle stops at a barrier and the plate is reported but the car doesn't move for 30 seconds, then this delay should be set to say 60 seconds or more to prevent a duplicate read.

NOTE! When using triggered mode, it is recommended that you set the delay to 0 seconds.

Same Plate Character Distance: Set the number of characters that two readings of the same license plate must differ by to be considered different. The camera is capable of reading a plate several times as it passes through the field of view. If one character is misread on one of the reads, then by setting this value to 2 then both reads will contribute towards the reported plate text.

Maximum Slope Angle: Set the angle of slope of a plate that the engine should attempt to read up to (0-30°).

Maximum Recognition Period: Maximum time the OCR can spend reading one or more times the same plate (multiple samples) until making its final decision (ms)

Minimum Plates Occurrences: Minimum number of times the plate should be read within the "Max Recognition Period" before being reported.

Maximum Plates Occurrences: Set the maximum number of times that a plate should be read before being reported (this may happen before the timeout).

Reported Image: Define which image from the pool is returned with the meta data. A plate is normally read several times as it passes through the camera's field of view. You may want to use the latest (last) image for oncoming traffic and the first image for vehicles moving away from the camera.

OCR

In the OCR (Optical Character Recognition) tab you can set parameters to ensure the best possible recognition results.

OCR ✕

Minimum Global Confidence	<input type="text" value="80"/>	Minimum global confidence 1-100, plates under this confidence will be discarded
Minimum Character Confidence	<input type="text" value="70"/>	Minimum character confidence 1-100, characters under this confidence will be discarded
Analytics Complexity	<input type="text" value="Medium"/>	Tip: Set low if you're losing plates because lack of performance, Medium: default/normal scenario conditions, High: low quality video
Plate Finder Extra	<input checked="" type="checkbox"/>	Enhances plate finding algorithms for difficult scenarios

Minimum Global Confidence: Set the minimum confidence level that the whole license plate read must meet in order to be accepted. The global confidence is the average of all individual characters' confidences. The recommended value is 70. Set lower if you see some plates in very bad condition but want to read them.

NOTE! Setting the Minimum Global Confidence too low will cause the OCR engine attempt to read other items such as vehicle signage etc.

Minimum character Confidence: Set the minimum confidence level that a single character must meet in order to be accepted. The recommended value is 50.

NOTE! In regions with open grammars such as the USA keep these two values high, e.g. 90-80 respectively. Higher values mean a lower probability of false positives and a lower probability of missing plates.

Analytics Complexity: This is the complexity of the analytics to be applied during the ALPR Engine's stage of plate reading. Set this according to the OCR mode and type of traffic expected. There are three options.

Low: Recommended for very high-speed traffic where the OCR needs to work faster and your preference is for plate detection over perfect recognition.

Medium (Default) Recommended when the OCR mode is set to free-flow.

High: Recommended when the OCR mode is set to signal (triggered).

CAUTION! Higher complexities give more accurate reading but make the ALPR engine run slower.

Plate Finder Extra: This is the complexity of the analytics to be applied during the ALPR Engine's stage of plate finding. Set this to one of the following three values:

Low: apply up to 3 levels

Medium: apply up to 8 levels

High: apply up to 12 levels

CAUTION! Higher complexities give more accurate reading but make the ALPR engine run slower.

MMC

In the MMC (Make, Model, Color) tab you can set parameters to define the detection results.

The screenshot shows a configuration panel for the MMC (Make, Model, Color) tab. The panel has a dark blue header with the text 'MMC' and a close icon. Below the header, there are two main settings:

- Analytic:** A dropdown menu is set to 'Both'. To its right, there is explanatory text: 'MMC: Enable Make, Model and Color detection. Classification: Enable classification (Car, Truck, Van, Motorbike)'. The 'Both' option is highlighted in yellow.
- Confidence:** A numeric input field is set to '50'. To its right, there is explanatory text: 'Minimum confidence'.

Fig. 6: OCR

Analytic: The following options are available

- None:** Select to disable MMC and Classification
- MMC:** Select to enable Make, Model and Color detection.
- Classification:** Select to enable classification (Car, Truck, Van, Motorbike)
- Both(Default)** Select to enable enable MMC and Classification

Confidence: Set the minimum confidence level that the MMC and Classification analysis must meet in order to be accepted. The recommended value is 50 (default). Set lower if you see some vehicles in bad environment conditions but want to read them.

Reporting

Vaxtor LPR incl. Vehicle Make, Model, Color and Class App is able to output all plate reads in real time using a variety of standard protocols so that the plate reads can be accepted remotely by a variety of programs including MOBOTIXSYNC, which can accept and store plate reads in real time from hundreds cameras.

By selecting one of the listed protocols, a sub-menu will appear with fields for setting up parameters such as remote IP addresses etc.

Reporting ☰		
Retry Notifications	<input type="checkbox"/>	Retry failed notifications (MOBOTIX SYNC and JSON only)
Send Test	<input type="checkbox"/>	Send a fake read (TEST) when settings are stored or when the camera is started
Text Overlay		
MxMessage		
MOBOTIX HUB Analytic Event		
Enable	<input type="checkbox"/>	Enable MOBOTIX HUB Analytic Event reporting
MOBOTIX HUB Transaction		
Enable	<input type="checkbox"/>	Enable MOBOTIX HUB Transaction reporting
MOBOTIX SYNC		
Enable	<input type="checkbox"/>	Send all results to the configured MOBOTIX SYNC server
JSON		
Enable	<input type="checkbox"/>	Enable JSON HTTP/HTTPS POST reporting
XML		
Enable	<input type="checkbox"/>	Enable XML HTTP/HTTPS POST reporting
Milestone Analytic Event		
Enable	<input type="checkbox"/>	Enable analytic event reporting
TCP Client		
Enable	<input type="checkbox"/>	Enable TCP client reporting
TCP Server		
Enable	<input type="checkbox"/>	Enable TCP server reporting
FTP		
Enable	<input type="checkbox"/>	Enable FTP reporting
Network Optix		
Enable	<input type="checkbox"/>	Enable Network Optix reporting
Genetec Security Center		
Enable	<input type="checkbox"/>	Enable Genetec reporting
Genetec LPR Plugin		
Enable	<input type="checkbox"/>	Enable Genetec LPR Plugin reporting
UTMC		
Enable	<input type="checkbox"/>	Enable UTMC reporting

Basic Settings

Reporting ⊞		
Retry Notifications	<input checked="" type="checkbox"/>	Retry failed notifications (MOBOTIX SYNC and JSON only)
Retry Period	<input type="text" value="1"/>	Amount of seconds between notification retries
Send Test	<input type="checkbox"/>	Send a fake read (TEST) when settings are stored or when the camera is started

Retry notifications: Check to retry failed notifications (MOBOTIX SYNC and JSON only).

Retry period: Amount of seconds between notification retries.

Send test: Check to send a fake read (TEST) when settings are stored or when the camera is started.

Text Overlay

Text Overlay		
Overlay Template	<input type="text" value="\$date\$ - \$plateutf8\$"/>	Template to use on the overlay, check the manual for available keywords
Fade out timer	<input type="text" value="0"/>	Amount of seconds that the overlay will be visible or 0 to make it perpetual
Show plate image	<input type="checkbox"/>	Display a small image with the plate number detected
Image position (x)	<input type="text" value="5"/>	Coordinate position for the image (x)
Image position (y)	<input type="text" value="50"/>	Coordinate position for the image (y)

Text Overlay

Overlay Template: Define template to use on the overlay. Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

Fade out timer: Set the amount of seconds that the overlay will be visible or 0 to make it perpetual.

Show plate image: Check to display a small image with the container code detected.

Image position (x): x coordinate position for the image.

Image position (y): y coordinate position for the image.

MxMessage

MxMessage	
MxMessage Template	

MOBOTIX HUB Transaction: With the Analytics Events feature it is possible to send transaction data to a MOBOTIX HUB server over TCP/IPport.

Enable: Check to enable and configure MOBOTIX HUB Transaction reporting.

Port: MOBOTIX HUB Server TCP Port.

Template: Template used when reporting. Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

MOBOTIX SYNC

NOTE! The options in this section also apply to Vaxtor Helix servers.

MOBOTIX SYNC		
Enable	<input checked="" type="checkbox"/>	Send all results to the configured MOBOTIX SYNC server
URL	<input type="text"/>	MOBOTIX SYNC full URL address (https://mysync.server.com/sync)
API Key	<input type="text"/>	MOBOTIX SYNC API Key
Heartbeat	<input type="text" value="300"/>	Heartbeat timer in seconds (10 - 300) or 0 if heartbeat is disabled
Camera ID	<input type="text" value="1"/>	MOBOTIX SYNC camera ID assigned to this camera
Overview Camera ID	<input type="text" value="0"/>	MOBOTIX SYNC overview camera ID assigned to this camera (0 if none)
Sync lists	<input type="text" value="0"/>	Synchronize lists with MOBOTIX SYNC server

MOBOTIX SYNC: MOBOTIX SYNC protocol is an encrypted version of the Vaxtor protocol.

Enable: Check to enable and configure the reporting to a MOBOTIX SYNC server.

URL: Enter the full URL of your configured MOBOTIX SYNC server using this syntax https://<ip_or_server_name>/sync). When reporting to a Vaxtor Helix server, enter https://<ip_or_server_name>/helix6.

API Key: Enter the MOBOTIX SYNC (or Helix) API key generated from your server application.

Heartbeat: Sends a heartbeat every x seconds to the specified server (enter 0 to disable).

Camera ID: Enter MOBOTIX SYNC (or Helix) camera ID assigned to this particular camera.

Overview Camera ID: Enter the MOBOTIX SYNC (or Helix) overview camera ID assigned to this particular camera (set to 0 if none).

Sync lists: Synchronizes the lists with the MOBOTIX SYNC (or Helix) server.

JSON

JSON		
Enable	<input checked="" type="checkbox"/>	Enable JSON HTTP/HTTPS POST reporting
URL	<input type="text" value="https://myserver/"/>	Destination URL
Username	<input type="text"/>	Username to use on the authentication. Blank if none.
Password	<input type="text"/>	Password to use on the authentication. Blank if none.
JSON Template	<input type="text" value='{"plate":"\$plate\$", "date":"\$date\$", "ir'/>	Template to use on the message, check the manual for available keywords

JSON : JSON is a compact data format in an easy-to-read text form for data exchange between applications.

Enable: Check to enable and configure JSON HTTP/HTTPS POST reporting.

URL: Enter the destination URL (e.g., 3rd party server) where the generated meta data should be sent to.

Username: Username to be used for authentication (leave blank if no authentication is used).

Password: Password to be used for authentication (leave blank if no authentication is used).

JSON Template: Defines the content / scheme of the transmitted JSON notification. Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

XML

JSON		
Enable	<input checked="" type="checkbox"/>	Enable JSON HTTP/HTTPS POST reporting
URL	<input type="text" value="https://myserver/"/>	Destination URL
Username	<input type="text"/>	Username to use on the authentication. Blank if none.
Password	<input type="text"/>	Password to use on the authentication. Blank if none.
JSON Template	<input type="text" value='{"plate":"\$plate\$", "date":"\$date\$", "ir'/>	Template to use on the message, check the manual for available keywords

XML : XML is a compact data format in an easy-to-read text form for data exchange between applications.

Enable: Check to enable and configure XML HTTP/HTTPS POST reporting.

URL: Enter the destination URL (e.g., 3rd party server) where the generated meta data should be sent to.

Username: Username to be used for authentication (leave blank if no authentication is used).

Password: Password to be used for authentication (leave blank if no authentication is used).

XML Template: Defines the content / scheme of the transmitted XML notification. Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

Milestone Analytic Event

Milestone Analytic Event		
Enable	<input checked="" type="checkbox"/>	Enable analytic event reporting
URL	<input type="text" value="http://milestoneserver.com:9090/"/>	Destination URL
Camera name	<input type="text" value="10.X.X.X"/>	Camera name or IP address as defined in Milestone

Milestone Analytic Event: With the Analytics Events feature it is possible to send MAD (Milestone Alert Data) formatted alerts to the Milestone event server over TCP/IP

Enable: Check to enable and configure MOBOTIX HUB Analytic Event reporting.

URL: Enter the corresponding Milestone Server URL (e.g. http://milestoneserver.com:9090/)

Camera name: Enter the camera name or IP address of this camera as defined in Milestone.

TCP Client

TCP Client		
Enable	<input checked="" type="checkbox"/>	Enable TCP client reporting
Server IP	<input type="text"/>	Server IP to which the messages are going to be sent
Port	<input type="text" value="30001"/>	Server TCP port to which the messages are going to be sent
Template	<input type="text" value="@\${plateutf8}\${@}"/>	Template to use on the message, check the manual for available keywords

TCP Client:

Enable: Check to enable and configure TCP client reporting

Server IP: Enter the URL of the server to which the MxMessages will be sent.

Port: Enter the TCP port of the server.

Template: Defines the content / scheme of the transmitted TCP message. Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

TCP Server

TCP Server		
Enable	<input checked="" type="checkbox"/>	Enable TCP server reporting
Port	<input type="text" value="30000"/>	Server TCP port
Template	<input type="text" value="@\${plateutf8}\${@}"/>	Template to use on the message, check the manual for available keywords

TCP Server: You can send event data as text file and images files to a ftp server.

Enable: Check to enable and configure TCP server reporting.

Server IP: Enter the URL of the server to which the MxMessages will be sent.

Port: Enter the TCP port of the server.

Template: Defines the content / scheme of the transmitted TCP message. Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

FTP

FTP		
Enable	<input checked="" type="checkbox"/>	Enable FTP reporting
URL	<input type="text" value="ftp://myserver/"/>	Destination URL
Username	<input type="text"/>	Username to use on the authentication. Blank if none.
Password	<input type="text"/>	Password to use on the authentication. Blank if none.
Filename template	<input type="text" value="\$uuid\$.ftpfiletype\$"/>	Template to use for the filename.
Text file template	<input type="text" value="\$date\$, \$plateutf8\$"/>	Template to use for the content of the text file.
Upload image	<input type="checkbox"/>	Upload the OCR image
Upload overview image	<input type="checkbox"/>	Upload the overview image
Upload patch	<input type="checkbox"/>	Upload the plate patch
Upload text file	<input type="checkbox"/>	Upload the text file

FTP: You can send event data as text file and images files to a ftp server.

Enable: Check to enable and configure FTP server reporting.

URL: Destination URL for the FTP server.

Username: Username if required, blank if none.

Password: Password if required, blank if none.

Filename Template: Template to use for the filename.

Text file template: Template to use for the content of the text file.

Upload image: Enables the upload of an image.

Upload overview image: Enables the upload of an overview image.

Upload patch: Enables the upload of a plate patch image (crop of the recognized code).

Upload text file: Enables the upload of a text file.

Network Optix

Network Optix		
Enable	<input checked="" type="checkbox"/>	Enable Network Optix reporting
URL	<input type="text" value="https://nxserver:7001/"/>	Destination URL
Username	<input type="text"/>	Username to use on the authentication.
Password	<input type="text"/>	Password to use on the authentication.
Network Optix Camera Id	<input type="text"/>	Camera Id set in Network Optix Video Management Software
Source	<input type="text" value="LPR"/>	Source value sent with the generic event.
Caption	<input type="text" value="\$plateutf8\$"/>	Template to use for the caption.
Description	<input type="text" value="\$plateutf8\$ (\$country\$)"/>	Template to use for the description.

Network Optix: You can send event data to a Network Optix VMS server.

Enable: Check to enable and configure Network Optix server reporting.

URL: Destination URL for the Network Optix server.

Username: Username for authentication.

Password: Password for authentication.

Network Optix Camera ID: Camera ID as set in the Network Optix video management software.

Source: Source value sent with the generic event.

Caption: Template to use for the caption Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

Description: Template to use for the description. Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

Genetec Security Center

Genetec Security Center	
Enable	<input checked="" type="checkbox"/> Enable Genetec reporting
Installation type	Production <input type="text"/> Type of installation. Check with Genetec the correct type according with your license.
URL	<input type="text"/> Destination URL
Username	<input type="text"/> Username to use on the authentication.
Password	<input type="text"/> Password to use on the authentication.
Camera Logical Id	0 <input type="text"/> Camera Logical Id configured on Genetec Security Center
Template	\$plateutf8\$ Template to use for bookmarks and custom events.
Create bookmarks	<input checked="" type="checkbox"/> Create a new bookmark with each plate read
Raise custom events	<input checked="" type="checkbox"/> Raise a new custom event with each plate read
Custom Event Id	0 <input type="text"/> Custom Event Id

Genetec Security Center: You can send event data to a Genetec Security Center server.

Enable: Check to enable and configure Genetec Security Center server reporting.

Installation type: Select the installation type that corresponds to your license.

URL: Destination URL for the Genetec Security Center server.

Username: Username for authentication.

Password: Password for authentication.

Camera Logical ID: Camera ID as set in Genetec Security Center.

Template: Template to use for bookmarks and custom events. Check the [Variables / Template Fields, p. 45](#) [Variables / Template fields](#) for available keywords.

Create bookmarks: Creates a new bookmark with each plate read by the app.

Raise custom events: Raises a new custom event with each plate read by the app.

Custom Event ID: Set a custom event ID.

Variables / Template Fields

Vaxtor shared reserved variables

Variable	Category	Description	Example
\$absolutebottom\$	image	Plate bottom position based on the total image height (0-1).	0.44
\$absoluteleft\$	image	Plate left position based on the total image width (0-1).	0.59
\$absoluteright\$	image	Plate right position based on the total image width (0-1).	0.66
\$absolutetop\$	image	Plate top position based on the total image height (0-1).	0.37
\$blacklist\$	lists & conditions	Description on the blacklist linked to the code/plate.	
\$blacklistdescription\$	lists & conditions	Description specified in the blacklist record	Suspicious vehicle
\$bottom\$	image	Bottom coordinate for the code/plate on the image (pixels).	477
\$cameravid\$	other	Camera OCR ID	
\$category\$	plate info	License plate category for countries that support it	Private
\$charheight\$	plate info	Average character height (pixels).	33
\$class\$	analytics	Vehicle classification	Car
\$color\$	analytics	Vehicle color	White
\$confidence\$	plate info	Global confidence (0-100).	99

Configuration of Vaxtor LPR incl. Vehicle Make, Model, Color and Class App

Reporting

Variable	Category	Description	Example
\$country\$	plate info	3 letter country code	GER
\$date\$	date & time	ISO 8601 Date with UTC offset appended	2023-09-19T23:47:01.65+02:00
\$day\$	date & time	Day (UTC) in two digits. Includes leading zero if single-digit number.	19
\$direction\$	analytics	Enumerate with the vehicle direction (0: Unknown, 1: Towards, 2: Away, 3: Stopped)	1
\$dwelltime\$	analytics	Time spent in monitored area, in seconds	336
\$etx\$	other	End of text control character (HEX 03).	
\$formatted\$	plate info	Plate contents in human-readable format. Empty if no result.	LU CY 1909
\$height\$	image	OCR image height in px.	1080
\$hour\$	date & time	Hour (UTC) in two digits using the 24-hour clock. Includes leading zero if single-digit number.	23
\$ifblacklist\$	lists & conditions	If the plate is on the blacklist, returns the text between these templates.	\$ifblacklist\$ Content to append \$ifblacklist\$
\$iflist\$	lists & conditions	If the plate is on list, returns the text between these templates.	\$iflist\$ Content to append \$iflist\$
\$ifnolist\$	lists & conditions	If the plate is not on any list, returns the text between these templates.	\$ifnolist\$ Content to append \$ifnolist\$
\$ifnotblacklist\$	lists & conditions	If the plate is not on the	\$ifnotblacklist\$ Con-

Variable	Category	Description	Example
	ditions	blacklist, returns the text between these templates.	Content to append \$ifnot-blacklist\$
\$ifnotwhitelist\$	lists & conditions	If the plate is not on the whitelist, returns the text between these templates.	\$ifnotwhitelist\$ Content to append \$ifnot-whitelist\$
\$ifwhitelist\$	lists & conditions	If the plate is on the whitelist, returns the text between these templates.	\$ifwhitelist\$ Content to append \$ifwhitelist\$
\$image\$	image	Full image, JPEG encoded in base64.	
\$imageid\$	other	Signal ID in case of a trigger read.	
\$imagesize\$	image	Full image size in bytes	297249
\$left\$	image	Left coordinate for the code/plate on the image (pixels)	1255
\$localday\$	date & time	Day (local) in two digits. Includes leading zero if single-digit number.	15
\$localhour\$	date & time	Hour (local) in two digits using the 24-hour clock. Includes leading zero if single-digit number.	12
\$localmin\$	date & time	Minute (local) in two digits. Includes leading zero if single-digit number.	23
\$localmonth\$	date & time	Month (local) in two digits. Includes leading zero if single-digit number.	11

Configuration of Vaxtor LPR incl. Vehicle Make, Model, Color and Class App

Reporting

Variable	Category	Description	Example
\$localsec\$	date & time	Second (local) in two digits. Includes leading zero if single-digit number.	48
\$localyear\$	date & time	Year (local) in four digits	2024
\$make\$	analytics	Vehicle make	Audi
\$min\$	date & time	Minute (UTC) in two digits. Includes leading zero if single-digit number.	47
\$month\$	date & time	Month (UTC) in two digits. Includes leading zero if single-digit number.	11
\$model\$	analytics	Vehicle model	Q3
\$multiplate\$	plate info	Amount of times that the plate has been read before reporting	4
\$nolist\$	lists & conditions	True or False	
\$overviewimage\$	image	Overview JPEG image encoded in base64.	
\$overviewimagesize\$	image	Overview image size in bytes.	297249
\$overviewimagejpegsize\$	image	Size of overview image size in bytes	8836
\$plate\$:	plate info	License plate text / number	LUCY1909
\$plateimage\$	image	Plate crop JPEG image encoded in base64	3564
\$plateimagesize\$	image	Plate patch image size in bytes	3881
\$platejpegsize\$	image	JPEG size in bytes	

Variable	Category	Description	Example
\$plateutf8\$	plate info	License plate text / number in UTF8 format	LUCY1909
\$processingtime\$	Plate info	Processing time in milliseconds.	122
\$right\$	image	Right coordinate for the code/plate on the image (pixels)	1269
\$roid\$	plate info	Recognition Area ID where the license plate number is found	1
\$sec\$	date & time	Second (UTC) in two digits. Includes leading zero if single-digit number.	10
\$sensor\$	other	Camera sensor ID where the plate number is found (0, 1).	0
\$signalid\$	plate info	Identificator provided on the triggering HTTP request	ab12cd34
\$speed\$	analytics	Vehicle speed (km/h)	123
\$state\$	plate info	License plate code state (for US license plates codes only)	Florida
\$stx\$	other	Start of text control character (HEX 02).	
\$tag\$	plate info	Hashed plate number. Same plate produces the same hash on repetitions.	9612548
\$timestamp\$	date & time	ISO 8601 date with UTC offset appended (yyyy-MM-ddTHH:mm:sszzz)	2024-09-19T23:47:01.65+02:00
\$top\$	image	Top coordinate for the	456

Variable	Category	Description	Example
\$utctime\$	date & time	code/plate on the image (pixels).	
\$utctime\$	date & time	ISO 8601 date UTC	2024-09-19T21:47:01.65Z
\$uuid\$	plate info	Universally unique identifier (UUID) generated at the time of license plate detection.	de5027d5-191d-4d3d-987b-dc104cc27d5c
\$vehicleaccess\$	analytics	Status: "Enter", "Exit", "Overstay", or "Lost"	
\$whitelistdescription\$	lists & conditions	Description specified in the Whitelist record	Mr Smith's car
\$width\$	image	Full image width in px	1254
\$year\$	date & time	Year (UTC) in four digits	2023

Genetec LPR Plugin

Genetec LPR Plugin

Enable Enable Genetec LPR Plugin reporting

URL Destination URL

Username Username to use on the authentication. Blank if none.

Password Password to use on the authentication. Blank if none.

Camera ID Unique Camera identifier.

Camera name Camera name.

Latitude Camera position latitude in decimal degrees format. E.g. 0.00000 or -0.00000. For wrong latitude and longitude values, the default value will be 0 for both

Longitude Camera position longitude in decimal degrees format. E.g. 0.00000 or -0.00000. For wrong latitude and longitude values, the default value will be 0 for both

Genetec LPR Plugin: You can send event data to a Genetec LPR Plugin server.

Enable: Check to enable and configure Genetec LPR Plugin server reporting.

Installation type: Select the installation type that corresponds to your license.

URL: Destination URL for the Genetec Security Center server.

Username: Username for authentication.

Password: Password for authentication.

Camera ID: Add a unique camera identifier.

Camera name: Add a name for this camera for easy identification.

Latitude: Latitude of camera position in decimal degrees from 0.00000 to 360.00000.

Longitude: Longitude of camera position in decimal degrees from 0.00000 to 360.00000.

NOTE! If one of the Longitude/Latitude values is invalid, the app will assume latitude/longitude values of 0.00000/0.00000.

UTMC

You can send LPR event data to a Urban Traffic Management and Control System.

UTMC		
Enable	<input checked="" type="checkbox"/>	Enable UTMC reporting
ID	<input type="text" value="1"/>	Camera ID
URL	<input type="text"/>	Destination URL
Username	<input type="text"/>	Username to use on the authentication.
Password	<input type="text"/>	Password to use on the authentication.
Allow empty responses	<input checked="" type="checkbox"/>	Allow empty responses as valid ones
Send plates in realtime	<input checked="" type="checkbox"/>	Try to send plate number as soon as it is read
Send plate number	<input checked="" type="checkbox"/>	Send plate number field
Send tag	<input type="checkbox"/>	Send tag field (anonymized plate number)
Send OCR image	<input checked="" type="checkbox"/>	Send the OCR image as ANPRIImage
Send plate patch	<input checked="" type="checkbox"/>	Send plate patch as platePatch
Send overview image	<input checked="" type="checkbox"/>	Send overview image as overviewImage
Heartbeat period (seconds)	<input type="text" value="60"/>	
Diagnostic period (seconds)	<input type="text" value="60"/>	
Retry period (seconds)	<input type="text" value="60"/>	
Plates per package	<input type="text" value="1"/>	

- **Enable:** Check to enable and configure UTMC reporting.
- **Installation type:** Select the installation type that corresponds to your license.
- **URL:** Destination URL for the Genetec Security Center server.
- **Username:** Username for authentication.
- **Password:** Password for authentication.
- **Camera Logical ID:** Camera ID as set in Genetec Security Center.
- **Template:** Template to use for bookmarks and custom events. Check the [Variables / Template Fields](#), [p. 45Variables / Template fields](#) for available keywords.
- **Create bookmarks:** Creates a new bookmark with each plate read by the app.
- **Raise custom events:** Raises a new custom event with each plate read by the app.
- **Custom Event ID:** Set a custom event ID.

Advanced

In this section you find useful tools for calibration and trouble shooting.

Advanced		
Log level	info	Info: Default log level. Debug: Enable debug log level, useful to diagnostic messages received from third parties. Trace: Enable trace log level, useful to diagnostic messages sent to third parties.
Show Log File On Screen	<input type="checkbox"/>	If enabled, the on-screen log file will be displayed on the selected sensor
Sensor	Right sensor	Sensor where the on-screen log file is displayed
Show Calibration Grid	<input type="checkbox"/>	If enabled, display on the OCR sensor a 20 pixels height grid

Log level: Select a debug level to generate a log file, which can be helpful e.g. for trouble shooting.

Info: Default log level

Trace: Select e.g. for diagnostic messages received from third parties

Debug: Select for complete log files for debug purposes

Show log file on screen: Check to display the on-screen log file on the selected sensor

Sensor: Select the sensor on which the on-screen log file is displayed

Show Calibration Grid: Check to display on the OCR sensor a 20 pixels height grid

Storing the Configuration

To store the configuration you have the following options:



- Click **Set** to activate your settings and to save them until the next reboot of the camera.
- Click **Factory** to load the factory defaults for this dialog (this button may not be present in all dialogs).
- Click **Restore** to undo your most recent changes that have not been stored in the camera permanently.
- Click **Close** to close the dialog. While closing the dialog, the system checks the entire configuration for changes. If changes are detected, you will be asked if you would like to store the entire configuration permanently.

After successfully saving the configuration, the event and meta data are automatically sent to the camera in case of an event.

MxMessageSystem

What is MxMessageSystem?

MxMessageSystem is a communication system based on name oriented messages. This means that a message must have a unique name with a maximum length of 32 bytes.

Each participant can send and receive messages. MOBOTIX cameras can also forward messages within the local network. This way, MxMessages can be distributed over the entire local network (see Message Area: Global).

For example, a MOBOTIX 7 series camera can exchange a MxMessage generated by a camera app with an Mx6 camera that does not support certified MOBOTIX apps.

Facts about MxMessages

- 128-bit encryption ensures privacy and security of message content.
- MxMessages can be distributed from any camera of the Mx6 and 7 series.
- The message range can be defined individually for each MxMessage.
 - **Local:** Camera expects a MxMessage within its own camera system (e.g. through a Certified App).
 - **Global:** the camera expects a MxMessage that is distributed in the local network by another MxMessage device (e.g. another camera of the 7 series equipped with a certified MOBOTIX app).
- Actions that the recipients are to perform are configured individually for each participant of the MxMessageSystem.

MxMessageSystem: Processing the automatically generated app event

Checking automatically generated app events

NOTE! After successfully activating the app (see [Activation of the Certified App Interface, p. 25](#)), a generic message event for this specific app is automatically generated in the camera.

1. Go to **Setup-Menu / Event Control / Event Overview**. In section **Message Events** the automatically generated message event profile is named after the application (e.g. VaxALPRMMC).

Environment Events				<input checked="" type="checkbox"/>
Image Analysis Events				<input checked="" type="checkbox"/>
Internal Events				<input checked="" type="checkbox"/>
Message Events				<input checked="" type="checkbox"/>
ColorRecognition	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	Edit... 1
FFLPR_MMCR	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
MxActivitySensor	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
MxAnalytics	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
ObjRec	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
VaxALPR	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
VaxALPRMMC	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
Meta Events				<input checked="" type="checkbox"/>
Signal Events				<input checked="" type="checkbox"/>
Time Events				<input checked="" type="checkbox"/>

Fig. 7: Example: Generic message event from Vaxtor LPR incl. Vehicle Make, Model, Color and Class App

2. Click **Edit** ① to display and configure the event properties in detail.

The screenshot displays a configuration window for an event named 'VaxALPRMMC'. At the top, there are controls for 'Inactive' and 'Delete'. The main configuration area includes:

- Event Dead Time:** A dropdown menu set to '5'. Description: 'Time to wait [0..3600 s] before the event can trigger anew.'
- Event Sensor Type:** Radio buttons for 'IP Receive' and 'MxMessageSystem' (selected). Description: 'Choose the message sensor.'
- Event Description:** A blue box containing the text 'Event on receiving a message from the MxMessageSystem.'
- Message Name:** A text input field containing 'VaxALPRMMC'. Description: 'Defines an MxMessageSystem name to wait for.'
- Message Range:** A dropdown menu set to 'Local'. Description: 'There are two different ranges of message distribution: *Global*: across all cameras within the current LAN. *Local*: camera internal.'
- Filter Message Content:** A dropdown menu set to 'No Filter'. Description: 'Optionally choose how to ignore messages containing *Filter Value*. Select *No Filter* to trigger on any message with defined *Message Name*.'

At the bottom left, there is a button labeled 'Add new profile'.


Fig. 8: Example: Generic message event details - no filter

Action handling - Configuration of an Action Group


CAUTION! To use events, trigger Action Groups or record images the general arming of the camera must be enabled ([http\(s\)/<camera IP address>/control/settings](http(s)/<camera IP address>/control/settings))

An Action Group defines which action(s) is (are) triggered by the Vaxtor LPR incl. Vehicle Make, Model, Color and Class App event.

1. In the camera web interface, open: **Setup Menu / Action Group Overview** ([http\(s\)://<camera IP address>/control/actions](http(s)://<camera IP address>/control/actions)).




2. Click **Add new group** ① and give a meaningful name.
3. Click **Edit** ②, to configure the group.



4. Enable **Arming** ① of the Action Group.
5. Select your message event in the **Event Selection** list ②. To select multiple events, hold the shift key.
6. Click **Add new Action** ③.

7. Select a proper action from list **Action Type and Profile** ④ .



NOTE! If the required action profile is not yet available, you can create a new profile in the Admin Menu sections "MxMessageSystem", "Transfer Profiles" and "Audio and VoIP Telephony".


If necessary, you can add further actions by clicking the button again. In this case, please make sure that the "action chaining" is configured correctly (e.g. at the same time).

8. Click on **Set** ⑦ to confirm the settings.


9. Click on **Close** ⑧ to save your settings permanently.

Action settings - Configuration of the camera recordings

1. In the camera web interface, open: **Setup Menu / Event Control / Recording** (http(s)/<camera IP address>/control/recording).



2. Activate **Arm Recording** (1) .
3. Under **Storage Settings / Recording (REC)** select a **Recording mode** (2) . The following modes are available:
 - Snap Shot Recording
 - Event Recording
 - Continuous Recording
4. In list **Start recording** (3) select the message event just created.
5. Click on the **Set** (4) to confirm the settings.


6. Click on **Close**  to save your settings permanently.

NOTE! Alternatively, you can save your settings in the Admin menu under Configuration / Save current configuration to permanent memory.

Advanced Configuration: Processing the meta data transmitted by apps

Meta data transferred within the MxMessageSystem

For each event, the app also transfers meta data to the camera. This data is sent in the form of a JSON schema within a MxMessage.



```
{
  "local" :
  {
    "VaxALPRMMC" :
    {
      "custom" :
      {
        "area" : "-1",
        "direction" : "1"
      },
      "vehicle" :
      {
        "Class" : "Car",
        "Color" : "Black",
        "Confidence" : "96",
        "Country" : "DEU",
        "LicensePlate" : „BVB“1909,
        "LicensePlateFormatted" : „B VB1909“,
        "List" : "Not listed",
        "Make" : "Mercedes-Benz",
        "Model" : "CLA",
        "Region" : "Stuttgart, Baden-Württemberg",
        "Time" : "2021-03-08T16:15:05.459+01:00"
      }
    }
  }
}
```

Fig. 9: Example: Meta data transmitted within a MxMessage of the Vaxtor LPR incl. Vehicle Make, Model, Color and Class App

NOTE! To view the meta data structure of the last App event, enter the following URL in the address bar of your browser: [http\(s\)://IPAdresseOfYourCamera/api/json/messages](http(s)://IPAdresseOfYourCamera/api/json/messages)

Creating a Custom Message Event

1. Go to **Setup-Menu / Event Control / Event Overview**. In section **Message Events** the automatically generated message event profile is named after the application (e.g. VaxLPRMMC).

Environment Events				<input checked="" type="checkbox"/>
Image Analysis Events				<input checked="" type="checkbox"/>
Internal Events				<input checked="" type="checkbox"/>
Message Events				<input checked="" type="checkbox"/>
ColorRecognition	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	Edit... 1
FFLPR_MMCR	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
MxActivitySensor	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
MxAnalytics	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
ObjRec	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
VaxALPR	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
VaxALPRMMC	MxMessageSystem	<input type="checkbox"/> Inactive	<input type="checkbox"/> Delete	
Meta Events				<input checked="" type="checkbox"/>
Signal Events				<input checked="" type="checkbox"/>
Time Events				<input checked="" type="checkbox"/>

- Click **Edit** ¹ to display and configure the event properties in detail.

The screenshot shows the configuration window for an event named 'VaxALPRMMC'. The window has a blue header with the event name, an 'Inactive' checkbox, and a 'Delete' button. The main area is divided into several sections:

- Event Dead Time:** A dropdown menu set to '5'. Description: Time to wait [0..3600 s] before the event can trigger anew.
- Event Sensor Type:** Radio buttons for 'IP Receive', 'MxMessageSystem' (selected), and 'MQTT Subscription'. Description: Choose the message sensor.
- Event on receiving a message from the MxMessageSystem.** A blue bar with the text 'Event on receiving a message from the MxMessageSystem.'
- Message Name:** A text input field containing 'VaxALPRMMC.plate.LicensePlate' (2). Description: Defines an MxMessageSystem name to wait for.
- Message Range:** A dropdown menu set to 'Local'. Description: There are two different ranges of message distribution: *Global*: across all cameras within the current LAN. *Local*: camera internal.
- Filter Message Content:** A dropdown menu set to 'JSON Comparison'. Description: Optionally choose how to ignore messages containing *Filter Value*. Select *No Filter* to trigger on any message with defined *Message Name*. The *Boolean Filter* triggers on JSON values true/false, or 1/0, and for some JSON strings like "on"/"off", "yes"/"no". For *JSON Comparison*, *Regular Expression*, *Value Filter*, and *Interval Notation* define the compared value as *Filter Value* below.
- Filter Value:** A text input field containing '"LUCY8000"' (3). Description: Define either a valid reference value as a string (in JSON format) without line breaks, or an extended regular expression, a number, or a minimum/maximum interval (a;b). Open help for examples.

At the bottom of the window, there are four buttons: 'Set' (3), 'Factory', 'Restore', and 'Close' (4).

Fig. 10: Example: Unique license plate event

- Click on the event (e.g. VaxALPRMMC) s to open the event settings.
- Configure the parameters of the event profile as follows:
 - **Profile Name:** Enter a meaningful profile name that illustrates the purpose of the profile.
 - **Message Name:** Enter the "Message Name" according to the event documentation of the corresponding app (see [Examples for message names and filter values of the Vaxtor LPR incl. Vehicle Make, Model, Color and Class App](#), p. 64).
 - **Message Range:**
 - Local: Default settings for the Vaxtor LPR incl. Vehicle Make, Model, Color and Class App
 - Global: (MxMessage is forwarded from another MOBOTIX camera in the local network).
 - **Filter Message Content:**
 - **No Filter:** Trigger on any message according to the defined **Message Name**.
 - **JSON Comparison:** Select if filter values are to be defined in JSON format.
 - **Regular Expression:** Select if filter values are to be defined as regular expression.

- **Filter Value:** see [Examples for message names and filter values of the Vaxtor LPR incl. Vehicle Make, Model, Color and Class App, p. 64](#)

CAUTION! “Filter Value“ is used to differentiate the MxMessages of an app / bundle. Use this entry to benefit from individual event types of the apps (if available).

Choose “No Filter” if you want to use all incoming MxMessages as generic event of the related app.

5. Click on the **Set** ④ to confirm your settings.
6. Click on **Close** ⑤ to save your settings permanently.

Examples for message names and filter values of the Vaxtor LPR incl. Vehicle Make, Model, Color and Class App

	MxMessage-Name	Filter value
Generic Event	VaxALPRMMC	
LPR White list Event	VaxALPRMMC.vehicle.List	“White list”
LPR Black list Event	VaxALPRMMC.vehicle.List	“Black list”
LPR Not listed Event	VaxALPRMMC.vehicle.List	“Not listed”
Unique license plate event	VaxALPRMMC.plate.LicensePlate	License plate code as “STRING”; e.g. “BVB1909” (compare Meta data transferred within the MxMessageSystem, p. 61)
Country Event	VaxALPRMMC.vehicle.Country	Country Code e.g. “DEU” for Germany
Incoming Vehicle Event	VaxALPRMMC.custom.direction	“1”
Outgoing Vehicle Event	VaxALPRMMC.custom.direction	“2”

MOBOTIX

BeyondHumanVision

[EN_02/25](#)

MOBOTIX AG • Kaiserstrasse • D-67722 Langmeil • Tel.: +49 6302 9816-103 • sales@mobotix.com • www.mobotix.com

MOBOTIX is a trademark of MOBOTIX AG registered in the European Union, the U.S.A., and in other countries. Subject to change without notice. MOBOTIX do not assume any liability for technical or editorial errors or omissions contained herein. All rights reserved. © MOBOTIX AG 2021