


User manual

XProtect® LPR 2024 R2

© 2024 MOBOTIX AG



Contents

Adding LPR content to your views	3
Adding LPR content	3
Add LPR cameras to views	3
Adjust LPR view settings	3
Enable LPR server status on maps	3
Enable LPR-specific elements	4
Viewing LPR related content	6
License plate recognition	6
LPR in live mode	6
LPR on the Search tab	6
The LPR tab	6
LPR event list	6
License plate styles	7
Filtering LPR events	7
Edit match lists	8
Import or export match lists	8
Export LPR events as a report	9
LPR on the Alarm Manager tab	10
View LPR recognitions	10

Adding LPR content to your views

Adding LPR content

Add LPR cameras to views

1. In **Setup** mode, select the view you want to add an LPR camera to.
2. In the **System overview** pane, click **LPR** and drag it to the relevant view item.
3. In the **Select LPR camera** dialog box, expand the required server to view a list of available LPR cameras from that server.


You can specify how you want to display LPR camera events in live mode in the **Properties** pane (see [Adjust LPR view settings on page 3](#)).

Adjust LPR view settings

1. In live mode, click **Setup**.
2. In **Properties**, next to **LPR camera**, click the **Browse** button to open the **Select LPR camera** dialog box and select another LPR camera.
3. Choose the order of LPR events in your lists on the right-hand side of the preview:
 - **Newest on top**: Display the newest LPR events at the top of the list
 - **Newest on bottom**: Display the newest LPR events at the bottom of the list
4. If you want to display the list of license plates from one camera but want to view video from another, select a different camera in the **Camera name** field.

Enable LPR server status on maps


It is possible to visualize LPR servers on maps and have their current status shown on the maps. To enable the LPR server status on maps:


1. In live mode, click **Setup**.
2. In **Views**, select the relevant map.
3. Right-click the map and select **Toolbox**.
4. In the toolbox, click the  **Add plug-in element** icon to open the **Element selector** window.
5. Select the relevant LPR server and drag it onto the map.
6. On the map, right-click the LPR server icon and select **Status details** to get live status on the LPR server and the LPR cameras related to the server.

You can associate the LPR specific map with your **Alarm list** by adding the map on the **Alarm Manager** tab.


Enable LPR-specific elements

To be able to see all relevant information regarding LPR recognitions in your MOBOTIX HUB Desk Client, on the **Alarm Manager** tab, do the following:

1. On the **Alarm Manager** tab, in the **Alarms** list, right-click the **Image** icon  next to the **Quick Filters** column. From the menu, select: **Object**, **Tag**, and **Type**.



2. Now **Type** displays all events related to LPR, **Tag** displays their country codes, and **Object** displays license plate numbers of the registered vehicles.



Viewing LPR related content

License plate recognition

LPR in live mode

In live mode, you can view live video from the cameras that have been configured for license plate recognition (LPR). You can view video from several LPR cameras in a view at the same time. On the right-hand side of the view item, the LPR events appear whenever there is a match. In setup mode, you can change the settings that define how the list of license plate numbers displays.

When you click a license plate in the LPR event list, the live video automatically pauses and changes to independent playback. To go back to viewing live video, either click the license plate again or click the **Independent playback** icon on the camera toolbar.

LPR on the Search tab

On the **Search** tab, you can search for video recordings associated with vehicles.

The LPR tab

On the **LPR** tab, you can investigate LPR events from all your LPR cameras and view the associated video recordings and license plate recognition data. Keep match lists updated and create reports.

The tab includes an LPR event list and an LPR camera preview. In the preview, you can view video associated with LPR event details. Below the preview, information about the license plate appears together with details from the match list and the license plate style that it is associated with.

You can filter the event list according to the period, country module, LPR camera, match list, or license plate style. Use the **Search registration number** field to search for a particular license plate registration number. By default, this list shows LPR events from the last hour.

You can specify and export a report of relevant events as PDF.

You can make updates to the existing match lists by using the **Match list** function.

LPR event list

The LPR event list displays all LPR events. By default, the list displays LPR events from the last hour and with the newest at the top, but your system administrator can change this.

When you select an LPR event from the list, you can see a preview to the right with the related video sequence for the event. The title bar of the preview shows the name of the LPR camera that the LPR event was triggered from. You also see the:

- License plate number
- Country module
- Time of the event
- Match list that triggered the event
- License plate style (see [License plate styles on page 7](#))

You can change how the LPR event list displays events; you can sort the columns and you can drag them to different positions. You can use the filters at the top of the list to filter LPR events or use the **Search registration number** field to search.



The LPR event list only displays LPR events from the time of your search or filter. If you want to see the latest LPR events, click the **Refresh** button.

License plate styles

A license plate style is a set of characteristics of a license plate, including the:

- Plate size and shape
- Text format and font
- Colors
- Type of vehicle that the license plate is used on

Your system administrator can group license plate styles and give that group a custom name.



You can only add those license plate styles to match lists that were grouped and named by your system administrator.

Filtering LPR events

There are several ways you can filter the LPR event list, so it displays just the LPR events that you are interested in; you can click any of the filters at the top of the list to see only LPR events associated with that filter. Any filters you apply are immediately reflected in the list.

- **Period:** Select one of the available periods to see LPR events within that particular time
- **Country module:** Clear or select country modules to view only LPR events linked to a license plate from a particular country, state, or region
- **LPR camera:** Select one or more of the available LPR cameras to view only LPR events for those cameras
- **Match list:** Select one or more license plate lists to view only LPR events generated by those lists
- **License plate style:** Select one or more license plate styles to view only LPR events associated with those license plate styles

You can combine the filters, for example, for a particular country module on a certain date.

You can also use the **Search registration number** field to search for a particular license plate. Enter a combination of characters to find results with combinations of those characters. For example, if you enter the characters **XY 12** you will get license plates that have both XY and 12 in their number. If you enter **XY12** you will only get license plates that have XY12 in their number.

Edit match lists

You can add and delete license plates from match lists.

1. On the **LPR** tab, in the top-right corner of the window, click **Match lists** to open the **Match lists** dialog box.
2. In **Select match list**, select the list that you want to edit.
3. To add a license plate registration number or a license plate style, click **Add**. Enter relevant information and click **OK**.



You can only add those license plate styles to match lists that were grouped and named by your system administrator.

4. To edit an existing license plate registration number, you can use the search function to find the relevant registration number.
5. Double-click a single row to edit or select multiple rows and click **Edit**.
6. In the dialog box, enter information and click **OK**. If the match list contains multiple columns, you can edit the information in all fields.
7. To remove a license plate registration number, you can use the search function to find the relevant registration number.
8. Select multiple rows if needed and click **Delete**.
9. Click **Close**.



Alternatively, you can add a license plate to a match list by right-clicking an unlisted LPR event and selecting **Add to list**. You can also remove a license plate by selecting the relevant LPR event, and on the right, below the preview, clicking the **Remove from list** icon.

Import or export match lists

You can import a file with a list of license plates that you want to use in a match list. You have the following import options:

- Add license plates to the existing list
- Replace the existing list

This is useful if, for example, the lists are managed from a central location. Then they can keep all local installations updated by distributing a file.

Similarly you can export the complete list of license plates from a match list to an external location.

1. To import a match list:
 1. On the **LPR** tab, at the top right of the window, click **Match Lists** to open the **Match Lists** dialog box.
 2. Select the relevant list.
 3. To import a file, click **Import**.
 4. In the dialog box, specify the location of the import file and the import type. Click **Next**.
 5. Await the confirmation and click **Close**.
2. To export a match list:
 1. Click **Export**.
 2. In the dialog box, specify the location of the export file and click **Next**.
 3. Click **Close**.
 4. You can open and edit the exported file in, for example, Microsoft Excel.



Supported formats are .txt or .csv.

Export LPR events as a report

You can export a report of LPR events to a PDF file.

1. On the **LPR** tab, filter or search for the events you want to include in the report.

If the number of found events is very high, you will receive a recommendation to refine the search and thereby reduce the number of search results.
2. Click the **LPR Report** button.
3. Specify the following values and click **OK**:
 - Report name
 - Report destination
 - A comment field
 - An option to include snapshots

A progress bar appears at the top right of the MOBOTIX HUB Desk Client window.

4. Click **Details** to view the report.



If you want to change the paper format or font, open the **Settings** window, select **Advanced**, and change the **PDF report format** or **PDF report font** settings.

LPR on the Alarm Manager tab

On the **Alarm Manager** tab, you can view and investigate alarms related to LPR. Some customization is required before you can view the information:

- [Enable LPR-specific elements on page 4](#)
- Alarms list must be in Event mode (see [View LPR recognitions on page 10](#))

In general, read the sections about alarm management for more details on MOBOTIX HUB Desk Client functionality.

View LPR recognitions


You can view LPR recognitions in the alarm list. If you select events as the data source, all recognitions are displayed. If you select alarms as the data source, only the recognitions associated with an alarm are displayed.

Requirements

To use the **Type** field referred to in the steps below, the field must be enabled in MOBOTIX HUB Management Client by your system administrator.

Steps:

1. Go to the **Alarm Manager** tab.
2. Click the **Setup** button to enter setup mode.
3. To view recognitions associated with an alarm:
 1. In the **Data Source** list, select **Alarm**.
 2. Select **Setup** again to exit setup mode and save your changes. The recognitions are displayed in the alarm list.
 3. To view incoming LPR alarms, enter **LPR** in the **Type** field.



The screenshot shows the 'Alarms' management interface. At the top, it says 'Alarms Custom (filter applied)' with a 'Clear filter' button. Below this are several filter fields: 'Priority level' (a range selector), 'State level' (set to 4), 'State name' (a dropdown), 'Source', 'ID', 'Owner', and 'Type' (containing 'LPR'). There are also 'Message' and 'Exclude closed alarms' (checked) options. On the right, there are 'From', 'To', and 'Servers' (checked, showing 'DKTA-1017CL0026') filters. A 'Reports' button and '1-4' are also visible.

4. To view all recognitions:
 1. In the **Data Source** list, select **Event**.
 2. Select **Setup** again to exit setup mode and save your changes. The recognitions are displayed in the alarm list.
 3. To view all incoming LPR events, enter **LPR** in the **Type** field.



The alarm list will display the filtered results only when you leave the field you modified.

MOBOTIX

BeyondHumanVision

MOBOTIX AG • Kaiserstrasse • D-67722 Langmeil • Tel.: +49 6302 9816 0 • sales@mobotix.com • www.mobotix.com

MOBOTIX is a trademark of MOBOTIX AG registered in the European Union, the U.S.A., and in other countries. Subject to change without notice. MOBOTIX do not assume any liability for technical or editorial errors or omissions contained herein. All rights reserved. © MOBOTIX AG 2024